



## RESOLVE® CARE AND MAINTENANCE

With regular care and maintenance, your Herman Miller Resolve furniture will provide many years of superior performance and satisfaction. To maintain the quality of your Herman Miller product, please follow the cleaning procedures outlined here.

The instructions for the care and maintenance of Herman Miller Products are provided to you as a service. No warranty is implied since results may vary.

### Resolve Canopy, Boundary Screen, Display Screen, and Rolling Screen Blankets

For normal cleaning, vacuum as needed, using an upholstery attachment. If further cleaning is needed, dry-clean or spot clean fabric with a solvent cleaner.

Do not over apply water or any liquid solution to fabric. Excessive wetting of the fabric with any liquid solution may result in permanent damage to the material.

Do not brush fabric or use a vacuum attachment with a rotary brush. Brushing may permanently damage the nap or change the character of the fabric.

Do not twist or pull on frame while cleaning. Such action may damage or alter shape of the frame.

### Formcoat® Finish

The Formcoat finishing process is a wood finishing process in which Herman Miller, Inc. powder coat paints medium density fiberboard (MDF). There are two types of Formcoat finishes: opaque and translucent. With the opaque finishes, you are unable to see any of the features of the raw MDF. The translucent finishes allow you to see through to the MDF.

For normal cleaning, wash with a soft cloth and a mixture of a mild detergent and warm water; wipe dry with a clean, soft cloth.

Avoid the following types of cleaning agents: Lysol cleaners, abrasive cleaners (Soft Scrub, Comet, etc.), and acetone bases cleaners.

For spot cleaning, spray with Fantastik®, 409®, or Kleerdex Company's Klear Off General Purpose Cleaners, and wipe until dry with a clean, soft cloth.

To clean metal marring, use a product call ZUD, which will remove the metal marring without changing the gloss or color of your Formcoat product.

Please handle with care! To avoid damage to Formcoat product, please follow these precautions:

- Do not drag across carpet or floor.
- Do not stand on the surface.
- Use care when using sharp objects near the surface.

PLEASE NOTE: Certain environments, such as laboratories or hospitals, are not well suited for Formcoat products due to the abnormally harsh chemicals that can reside in these areas and could damage the Formcoat finish.